



READ THIS FIRST

Failure to follow these simple instructions may result in damage to your new machine. Please follow these instructions carefully.

READ THIS PAGE BEFORE OPERATING YOUR VSE CK-MINI MACHINE

HOW TO ATTACH BLOWER HOSE & FLUID LINE

1. **ATTACH THE BLOWER HOSE** to the CK-Mini Machine by lining up hose and turning the hose collar clockwise to securely fasten the hose to the machine.
2. **ATTACH THE FLUID LINE** to the CK-Mini Machine by connecting the clear fluid line from the hose into the white connector on the machine. Insert until you hear a click or feel that it is completely inserted.


ELECTRICAL INFORMATION

When using your CK-Mini Machine, ensure that you are using a **HEAVY DUTY EXTENSION CORD (MAX LENGTH 50 FT.)**, such as the one shown below. **DO NOT** use a small extension cord that you would use for household items such as lamps or alarm clocks.



HOW TO REMOVE BLOWER HOSE & FLUID LINE

1. **REMOVE THE FLUID LINE** from the CK-Mini Machine by first pulling out the blue retainer clip from the white connector on the end of the fluid line that is attached to the blower hose.
2. Push down the small inner lip of the white connector.
3. Pull the clear fluid line out until it is completely removed and no longer connected to the machine.
4. Pull the small inner lip of the white connector back up and re-insert the small blue retainer clip. Make sure the tab on the small blue retainer clip is facing **UP**, as shown below.



5. **REMOVE THE BLOWER HOSE** from the CK-Mini Machine by simply turning the blower hose counter clockwise.